that the innermost Al2O3 tube melted over a length \simeq 10 cm. and the remaining aluminum metal formed a sharp cylindrical band, about 3 cm. wide and ~ 3 mm. thick, on the Al2O3, the two phases being perfectly defined and separate.

A ThO2 tube also has been melted in the plasma

The extended range of use of liquid oxide containers is, on the average

2288°K. (m.p.) to ~ 3800°K. Al₂O₈ 3000°K. (m.p.) to $\simeq 4600$ °K. ZrO2 3300°K. (m.p.) to $\simeq 4700$ °K. ThO2

The ratio of the vapor pressure of the container to the total pressure can be adjusted, as desired, by operating the plasma jet and furnace at a higher total pressure.

Thus a way is now open to extend research, particularly on chemical reactions in liquid phase, (for example, between the container and any added substance, lighter than the container) to a much higher temperature range. A full report will be published later.

The above method is not well suited for physical measurements (such as density, electrical resistivity, etc.) because of imperfect geometry. This can be accomplished by the use of centrifugal furnaces heated by ohmic resistance. This type of furnace will be described shortly.

RESEARCH INSTITUTE OF TEMPLE UNIVERSITY PHILADELPHIA 44, PA.

A. V. GROSSE H. W. LEUTNER
W. J. MURPHY
C. S. STOKES

RECEIVED JUNE 28, 1962