

extrapolating to the value of the lattice parameter characteristic of the fully ordered material to find  $R_0$  at 25°C and 1 atmosphere. The temperature and pressure coefficient of resistance of a highly ordered sample are then measured and used to find  $R_0(T, P)$ .

The procedure for measurement of the ordering rate is to first set up a quenched sample in the anvils and measure its resistance at room temperature and pressure. Then a pressure of a few hundred bars is applied and T raised to 100°C. At this temperature the sample is brought to the pressure to be used in the experiment; it is then rapidly heated and, when the temperature is stabilized, the resistance is measured as a function of time until the equilibrium resistance is attained. At the temperatures and pressures used, this may require a time between a few hours and a few days. During this anneal T is held to  $\pm 0.5^\circ\text{C}$  and P to within  $\pm 40$  bars.

The resistance changes during a typical ordering experiment are shown in Fig. 6. To the data points shown, Eq. 1 must be fitted. In making this fit allowance must be made for possible errors in the determination of  $R_0$  and  $R_e$ . This was done by means of a computer program which compares Eq. 1 with the data for the following range of the variables  $R_0$ ,  $R_e$ , and  $\alpha$ :

$$\Delta R_0 = 1.1 R_0 \text{ to } 0.7 R_0$$

$$\Delta R_e = 1.0 R_e \text{ to } 0.9 R_e$$

$$\Delta \alpha = 3.0 \alpha \text{ to } 0.3 \alpha$$